Split air conditioner
Wall mounted Type
Service manual

AUS-07C(H)53R010Lx
AUS-07C(H)53R150Lx
AUS-09C(H)53R150Lx
AUS-09C(H)53R010Lx
AUS-12C(H)53R150Lx
AUS-12C(H)53R130Lx

(X=1,2,3,4,5,6,14,15,16,.....)

CONTENTS

Contents 1

Safety precautions 2

Installation 2

Block diagram 11

Trouble shooting 12

Fault diagnosis by symptom 13

Control specification 17

To disassemble mechanical parts 21

Exploded views and parts list 25

Wiring diagrams 39

SAFETY PRECAUTIONS

The following safety precautions must be taken when using your air conditioner.

1. Warning: Prior to repair, disconnect the power cord.

2. Use proper parts: use only exact replacement parts. (Also, we recommend replacing parts rather than repairing them.)

3. Use the proper tools: use the proper tools and test equipment, and know how to use them. Using defective tools or test equipment may cause problems later-intermittent contact, for example.

4. Power cord: prior to repair, check the power cord and replace it if necessary.

5. Avoid using an extension cord, and avoid tapping into a power cord. This practice may result in malfunction or fire.

6. After completing repairs and reassembly, check the insulation resistance.
Procedure: prior to applying power, measure the resistance between the power cord and the ground terminal. The resistance must be greater than 30 megohms.

7. Make sure that the grounds are adequate.

8. Make sure that the installation conditions are satisfactory. Relocate the unit if necessary.

9. Keep children away from the unit while it is being repaired.

10. Be sure to clean the unit and its surrounding area.

INSTALLATION

Selecting area for installation

Select an area for installation that is suitable to the customer's needs.

1 Location of indoor unit

- Keep the air inlet and outlet at a far distance from the blockage.
- Keep the height distance between the indoor and outdoor unit at most 5m.
- Mount on the wall solid enough to bear the weight of the unit and not cause any shake.
- Avoid direct sunshine.
- A place easy for condensate drain and easy for connecting with the outdoor unit.
- Keep a far distance away from the fluorescent lamp, it may influence the operation of remote controller.
- Keep at least 1m away from the TV radio and other home appliances.

2 Location of outdoor unit

- A place solid enough to bear the weight of the unit and not cause any shake.
- Good ventilation, less dust, far from direct rain and sunshine.
- A place where the air discharged out of the outdoor unit or the operation noise will not annoy your neighbours.
- No blockage near the outdoor unit.
- Avoid places close to inflammable gas leakage.

Caution:

It is harmful to the air conditioner if it is used in the following environments: greasy areas (including area near machines). Salty area such as coastal areas, areas where sulfuric gas is present such as hot spring areas. Contact your dealer for advice.

Installation diagram of indoor unit and outdoor unit



Confirm the installation position by the mark of the indoor mounting plate.



The copper pipe can be led from back, right, underside, or left-back side.



Notice: do not elevate the drain hose.



While installing the pipeline on the thin armor plate or on the wall of metal mesh, you should use the wooden board to clamp between the wall and the pipeline, or wrap up the pipeline with 7-8 layers of insulating plastic tape.

Cover connecting pipe with adiabatic material.

Sponge plastic adiabatic material with the thickness of 8mm.



1 Securing the mounting plate and drill on the wall

- **Secure the mounting plate**

The mounting plate should be attached to the structural part of wall (post etc).





NOTICE:
- The holes at solid arrow position must be secured to avoid the shake of mounting plate.
- When the expansion bolts are used, two holes (11×20 or 11×26) that the distance between them is 450mm should be adopted.

- **Drill on the wall**





NOTICE: • Confirm the position of holes, and drill holes on the wall.





NOTICE:

- The holes at solid arrow position must be secured to avoid the shake of mounting plate.
- When the expansion bolts are used, two holes (11×20 or 11×26) that the distance between them is 450mm should be adopted.
- Confirm the position of holes, and drill holes on the wall.

2 Wiring

- Open the front grille;
- Remove the screw from electrical box cover, pull the electrical box cover away from the unit and set aside.
- Remove the screw from fastener, pull the fastener away from the unit and set aside.
- Connect the cable.
- Replace the fastener and electrical box cover.



NOTE:

The appliance shall be installed in accordance with national wiring regulations.
The appliance must not be installed in the laundry.
The appliance must be installed 2.3m above the floor.
The appliance must be positioned so that the plug is accessible.
For some models whose cooling capacity are above 4600W (17000BTU/h), an all-pole disconnection device which has at least 3mm separation distance in all pole and a residual current device(RCD) with the rating of above 10mA shall be incorporated in the fixed wiring according to the national rule.

3 Installation of the drain hose

■ NOTE:

- The drain hose must be arranged beneath the copper pipe.
- The drain hose must not be hunched or twisted.
- While wrapping up the drain hose, do not pull it.
- The drain hose through the room must be wrapped up by the thermal insulation materials.
- The copper pipe and the drain hose must be wrapped up by felt strip. Adiabatic pad should be used at where the pipe contacts the wall.



■ ROUTE OF PIPE

- If pipe comes out of the right side of the indoor unit, cut part "1" of the unit;
- If pipe comes out of the lower-right side of the indoor unit, cut part "2" of the unit;
- If pipe comes out of the left side of the indoor unit, cut part "3" of the unit.



■ REFIT OF DRAIN HOSE

- If pipe comes out of the left side of the indoor unit, the drain hose must be refitted, otherwise water leakage may occur.
- Refit methods: Interchange the position of drain hose and drain rubber plug.
- Clearance is not allowed after refit, it would lead to water leakage.



■ Arrangement of the drain hose

- To drain the condensate water easily, the drain hose should be declined downwards.
  The following 5 arrangement methods are incorrect.



(Fig. 1) (Fig. 2) (Fig. 3) (Fig. 4) (Fig. 5)

- If you find the drain hose not long enough to connect with the indoor unit, you can extend it with the hoses in the accessory box.
- The drain hose through the room must be wrapped up with the special adiabatic material.



4 Installation of the indoor unit

Let pipe go through the wall hole and attach the indoor unit to the mounting plate.(Press the rib of indoor unit inside the hook of the mounting plate.)



5 Pipe Connection

- The number of bent position of the pipe in the indoor unit should not exceed 10.
- The number of bent position of the pipe in the indoor unit and the outdoor unit should not exceed 15.
- The radius of bent position should be more than 10cm.
- Please break the evaporator craft tube with pincers before connecting. After exhausting the inside air, use the wrench to twist down the nut of connecting tube of the evaporator.
- Put some seal oil to cover the joint and the flare.
- Align the centre of joint in line with that of flare and tighten the nut of connecting pipe with wrench.

Attention:

Do not exhaust the inside air just by loosing the nut since there is the air of certain pressure inside the tube of indoor unit. Please do not make extra effort for fear of damaging the flare.

DIAMETER OF PIPE	TORQUE(N • m)
6.35mm (1/4")	13.7---17.6
9.52mm (3/8")	34.3---41.2
12.7mm (1/2")	49.0---56.4
15.88mm (5/8")	73.0---78.0

6 Wall sealing and Pipe fastening

- Use putty to seal the wall hole.
- Use clamp (pipe fastener) to secure the pipe at specified position.



INSTALLATION

Installation diagram of indoor unit and outdoor unit

1 Wiring



or



Wiring For Above 6000W Model (Above 21000BTU/h Model)

1 Remove the self-tapping screws (2 pcs) on the maintenance board and take out the maintenance board.



The cable wire can be led from the back hole of the piping hole or ejecting hole.

Please utilize outdoor pipe support when the cable wire is led from the backside.



2 Loosen the self-tapping screws (2 pcs) on the fixing clip to loosen the fixing clip.

3 Loosen the fixing screw of the wire terminal board, pass the power wire and signal wire through the fixing clip. Then firmly fix the power wire and signal wire on the terminal board with the fixing screw. (Earth wire must be connected firmly.)

4 Tighten the self-tapping screw on the fixing clip.

5 Install the maintenance board. After the pipes and cable wire are installed, please seal the sponge block as per drawing indication.





INSTALLATION

Notice:

- If the signal wire has to be bought separately, choose electric wire above 0.75mm^2.
- If the interconnection cord for power supply has to be replaced, please see the following table for reference.

MODEL	SPECS (Interconnection cord)
≤2700W(10000BTU/h)	≥1.0mm^2
3000W(11000BTU/h) -4000W(15000BTU/h)	≥1.5mm^2
4500W(18000BTU/h) -8000W(28000BTU/h)	≥2.5mm^2

WARNING:

- **Please take the electric circuit diagram attached to the indoor/outdoor units as major reference while installing.**
- **The power wire and signal wire between the indoor/outdoor units must be connected one by one as per corresponding number on the wiring terminal board.**
- **The connecting cables must be clipped together.**
- **Special cable must be used to connect indoor unit and outdoor unit. It should be ensured that the terminals are not influenced by external force. Poor connection may cause fire.**
- **The electric box cover must be mounted and secured in position, otherwise fire or electrical shock may occur because of dust or moisture.**
- **The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.**
- **All the models shall be connected with the mains which has system impedance limitations. While installing the unit, please see the following table for impedance information or consult with the supply authority.**

R410A series	3500W (12000BTU/h)	≤0.219 Ω
	5100W (18000BTU/h)	≤0.186 Ω
	6800W (18000BTU/h)	≤0.124 Ω

2 Installation of the drain joint(only for heat pump type)

- Insert the outdoor double-channel drain joint in one of the bottom holes of the suitable size then connect drain hose and joint together.



3 Joint of the connecting pipe

- Put some seal oil to cover the joint and the flare.
- Align the centre of joint in line with that of flare and tighten the nut of connecting pipe with wrench. (Adjust the torque by the same method of connecting pipe for indoor unit.)

4 Air exhausting

- Screw down the cap of both gas shut-off valve and liquid shut-off valve as well as the nut of service port.
- Use Allen wrench to turn the valve cork of liquid side at 90° counter-clockwise, and close it after 10 seconds. Use soapy water to check the gas leakage especially at all joint. If there is no gas leakage, please turn the valve cork of liquid side at 90° counter-clockwise again.
- Press the cork of service port at gas shut-off valve, 10 seconds later, when you see foggy gas discharged, that means inner air is exhausted out.
- Use Allen wrench to turn the valve cork of both liquid shut-off valve and gas shut-off valve counter-clockwise until they are completely open and then replace the valve caps and tighten them.



5 Process of flared tube

- Use the pipe cutter to cut off the broken part of flare.
- Remove burrs at the cut of the flare.
- Insert a nut into the connecting pipe and do flaring with specified flaring tools, reamers for example.

Remove burrs at the cut of the flare.

Outer diameter	A(mm)
6.35mm (1/4”)	2.0--2.5
9.52mm (3/8”)	3.0--3.5
12.7mm (1/2”)	3.5--4.0
15.88mm(5/8”)	4.0--4.5

- Check the quality of flaring technique.



6 Adding refrigerant

- If the connecting pipe is longer than 7 metres, add refrigerant as needed. (Cool only type) added amount A=(Lm-7m)×15g/m ; (Heat pump type)added amount A= (Lm-7m) ×50g/m. (A: amount of added refrigerant, L: the length of connecting pipe)

The length of connecting pipe (m)	7	8	9	10
(Cool only type)added amount (g)	0	15	30	45
(Heat pump type)added amount (g)	0	50	100	150

- Exhaust the air as the above-mentioned method.
- Screw the gas shut-off valve to close, connect charging hose(low pressure) to the service valve and then open gas shut-off valve again.
- Set the unit to cool operation mode.
- Connect the refrigerant bottle to the charging hose and then convert it.
- Fill in liquid refrigerant as the above table.
- Stop operation of the air conditioner.
- Disconnect the manifold gauge after turning off the shut-off valve, and then open gas shut-off valve again.
- Tighten nuts and caps of each valve.



7 Relocation of the air conditioner.

- Refer to this procedure when the unit is relocated.

1. Carry out the pump down procedure.
2. Remove the power cord.
3. Disconnect the assembly cable from the indoor and outdoor units.
4. Remove the flare nut connecting the indoor unit and the pipe.
   At this time, cover the pipe of the indoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering.
5. Disconnect the pipe connected to the outdoor unit.
6. Make sure you do not bend the connection pipes in the middle and store together with the cables.
7. Move the indoor and outdoor units to a new location.
8. Remove the mounting plate for the indoor unit and move it to a new location.

INSTALLATION

8 Operation test

- Before test operation, wiring safety inspection must be carried out carefully again.

1. Emergency switch operation: Every press of emergency switch, the air conditioner runs as in the following order:

   Cool only type: Cool → Shut off

   Heat pump type: Cool → Heat → Shut off

2. Remote controller operation: If the indoor unit sounds like Di, Di when pressing I/O button, that indicates the air conditioner is under the operation of remote controller. After that, press every button to test their functions.

3. Check switch operation: Open the front grille and press the check button. Switch on the power source and then the operation test is activated. If the indicator lamps light up at first and then go out in succession or the LED window of the indoor unit illuminates at first and then goes out, the system is under normal operation. If one of the indicator lamps is flashing at all times, or failure codes are displayed on the LED window of the indoor unit, the system has something wrong and please check malfunction immediately.

BLOCK DIAGRAM

Refrigerant Cycle Block Diagram



TROUBLE SHOOTING

Items to be checked first

1. Is the voltage of the power correct?
   The input voltage shall be rating voltage ±10%.
   The air conditioner may not operate properly if the voltage is out of this range.
2. Is the link cable connecting the indoor unit and the outdoor unit linked properly?
   Please refer to the "wiring diagram"
   Check the terminals if the indoor unit and outdoor unit are properly linked by the same number of cables.
3. When a problem occurs due to the contents illustrated in the table below, it is symptom not related to the malfunction of the air conditioner.

Operation of air conditioner	Explanation
In COOL operation mode, the compressor does not operate at a room temperature higher than the setting temperature that the indoor fan should operate. In a HEAT operation mode, the compressor does not operate at a room temperature lower than the setting temperature that indoor fan should operate.	It happens after a delay of 3 minutes when the compressor is reoperated. The same phenomenon occurs when a power is on. As a phenomenon that the compressor is reoperated after a delay of 3 minutes, the indoor fan is adjusted automatically with reference to a temperature of the air blow.
Fan speed setting is not allowed in AUTO or DRY mode.	The speed of the indoor fan is set to low in DRY mode. Fan speed of 3 steps is selected automatically in AUTO mode.
Compressor stops operation intermittently in DRY mode.	Compressor operation is automatically controlled in DRY mode depending on the room temperature and humidity.
Compressor of the outdoor unit is operating although it is turned off in HEAT mode.	When the unit is turned off while de-ice is activated, the compressor continues operation for up to 10 minutes(maximum) until the deice is completed.
Timer indicator lamp lights up and the air conditioner does not operate.	Timer is being activated and the unit is in ready mode. The unit operates normally if the timer operation is cancelled.
The compressor and indoor fan stop intermittently in HEAT mode.	The compressor and indoor fan stop intermittently if room temperature exceeds a setting temperature in order to protect the compressor from overheated air in HEAT mode.
Indoor fan and outdoor fan stop intermittently in HEAT mode.	The compressor operates in a reverse cycle to remove exterior ice in HEAT mode, and indoor fan and outdoor fan do not operate intermittently for within 20% of the total heat operation.
The compressor stops intermittently in COOL mode or DRY mode, and fan speed of the indoor unit decreases.	The compressor stops intermittently or the fan speed of the indoor unit decreases to prevent inside/outside air frozen depending on the inside/outside air temperature.

SELF DIAGNOSIS FUNCTION

Our company provides the end-users with thoughtful services by installing various diagnostic systems to indicate the following irregular performances.

Check code	Diagnosis of malfunction
FAULT F6	PG motor faults
FAULT F7	Indoor TEMP sensor faults
FAULT F8	Indoor coil pipe TEMP sensor faults
FAULT F9	Outdoor coil pipe TEMP sensor faults

Note: When the outdoor coil pipe TEMP sensor is out of order or removed, the air conditioner will set to defrost automatically in order to prevent it not working normally while the outdoor coil pipe TEMP sensor is malfunction.

FAULT DIAGNOSIS BY SYMPTOM


No cooling
No cooling effect at all
Fan motor error
Fan motor or its capacitor faults.
Loose connection or badly contact.
Control circuit error.
compressor does not operate
Voltage may appear a little lower or higher.
Loose or wrong connection.
Compressor faults or jumps for overloading.
Control circuit error.
Leakage of refrigerant
Recharge the refrigerant at leaking place.
Block of the cooling system
The capillary, pipeline are blocked or the valve is not open or the connecting tube is folded flat.
Poor cooling efficiency
Insufficient refrigerant
Some leakage in the valve.
Some cracks, welding failure in the system.
Extra fluorin is added during mounting.
Air filter is blocked
No periodical cleaning.
Accumulated lampblack, dust or contaminated ambient environment.
Poor efficiency of heat dissipating on the outdoor unit
Mounting location is not suitable, such as near the wall.
Air outlet is blocked or accumulated lampblack or dust is attached to the vane.
Too high ambient temperature
The outdoor unit gets exposed to the sun for too long period.
Not for residential use.
Air conditioning burden is not adequate for the room
The doors and windows are not closed well; too weak of input cooling power or too many heat resources in the room.
Low airflow volume
Low fan motor frequency or capacitor is not functional.
Low fan speed or the fan motor faults.
The four-way valve error
The distributing air of the four-way valve may have mixed together; the valve core or solenoid valve faults.
Blockage in the system
The valve is not completely open; the capillary or Pipeline is half blocked.
Connecting tube is folded flat.

FAULT DIAGNOSIS BY SYMPTOM


No heating
No heating effect at all
Fan motor error
Fan motor or its capacitor faults.
Loose connection or badly contact.
Control circuit error.
compressor does not operate
Voltage may appear a little lower or higher.
Loose or wrong connection.
Compressor faults or jumps for overloading.
Control circuit error.
Leakage of refrigerant
Recharge the refrigerant at leaking place.
Block of the cooling system
The capillary, pipeline are blocked or the valve is not open or the connecting tube is folded flat.
The four-way valve or solenoid valve faults.
The four-way valve did not commutate or the distributing air of the four-way valve may have mixed together.
Poor heating efficiency
Insufficient refrigerant
Some leakage in the valve.
Some cracks, welding failure in the system.
Extra fluorin is added during mounting.
Air filter is blocked
No periodical cleaning.
contaminated ambient environment.
Too low ambient temperature
Below 0℃.
Too thick frost generated on the condenser.
The condenser does not defrost, no smooth air circulation.
Extra refrigerant or mixing air in the system
Discharge the redundant refrigerator recharge the refrigerant after vacuum extraction.
Air conditioning burden is not adequate for the room
The doors and windows are not closed well; too weak of input cooling/heating power.
The condenser is too dirty
Accumulated lampblack or dust is attached to the vane.
The electric heater is not working
Not satisfy the conditions for electric heater running.
Plug cords may be loose.
Low airflow volume
Low fan motor frequency or capacitor is not functional.
Low fan speed or the fan motor faults.
The four-way valve error
The distributing air of the four-way valve may have mixed together; the valve core or solenoid valve faults.
Blockage in the system
The valve is not completely open; the capillary or Pipeline is half blocked.
Connecting tube is folded flat.

FAULT DIAGNOSIS BY SYMPTOM


Noisy
Noise from indoor unit
Collision sound of the machine
Fixing bolts somewhere may loose or rub, some spare parts may not match very well.
Flowing sound of the liquid
Refrigerant circulation or pressure change of refrigerant while switch on/off.
Sound of the running fan motor
Vane imbalance or distortion, rupture; loose screw of vane.
Sound of plastic pieces rubbing or deforming
Plastic pieces deform due to expansion when hot and shrink when cold. Or some spare parts may not match very well.
Noise from Outdoor unit
Collision sound of the machine
Collision of the pipeline, fixing screws loose or deform caused by rubbing.
Oscillation sound
Inappropriate installation method; the unit does not match with the installation kit very well or the compressor quivers acutely.
Sound of running fan motor
Vane imbalance or distortion.
Sound made by cooling operation
Refrigerant circulation or vane distortion.
Sound of running compressor
Something wrong with the compressor, such as oil shortage, valve slice distortion.
Noise from the whole unit
Resonance sound
The unit does not match with the installation kit very well
The whole unit resonates the door and window.
Collision sound of the machine
Collision of the pipeline, fixing screws loose or plastic pieces deform.
Sound made by compressor or motor
The compressor or motor makes abnormal noise.
Flowing sound of condensed water
Condensed water is attached to the vane.
Sound of running fan motor
Vane imbalance or distortion.

FAULT DIAGNOSIS BY SYMPTOM


Switching on the air conditioner
The current leakage switch jumps to turn off
Junction wire looses and collides with the outer cover.
Degraded capability of wire insulation.
Insulation capability of some components has lowered.
Check the resistance of every component by multimeter
Water comes into the plug or electric components.
The fuse is blown or air limit switch jumps to turn off
Is the voltage of power supply lower than 15% of rated voltage (220V)?
Yes
The voltage is low, please add manostat.
No
Short circuit somewhere.
Short circuit in the electric wire or connection wire.
Partially short circuit in some components.
Fuse capacity is adequate or not?
Yes
Check as the above -mentioned method.
No
Replace with adequate fuse.
Without any response
Check whether the receptacle has power or not.
Strong circuit breaks the circulation.
The transformer faults.
The main control board faults.
Power supply error

CONTROL SPECIFICATION

1 ABBREVIATION

ST: Setting Temperature
PT: Indoor coil Pipe Temperature
RT: Room Temperature
OT: Outdoor coil pipe temperature
OFAN: Outdoor fan
IFAN: Indoor fan
COMP: Compressor

2 OPERATION OF MAIN BOARD

■ COOL MODE

- The ST at cool mode is adjustable within 16℃-31℃.
- When RT≥ST, both the compressor and the outdoor fan start;
  When RT<ST-1℃, the compressor stops and 18 seconds later, the outdoor fan will stop.
  But the indoor fan keeps running at predetermined speed.
- Once turning on the unit while set at cool mode, the indoor fan immediately runs at predetermined speed; if all the conditions meet with the requirement of compressor operation, both the outdoor fan and compressor start running. If not, either the outdoor fan or compressor could start.
- The four-way valve keeps being off all the time at cool mode.

Condensate dew prevention

If the horizontal air flow louver is set at low angle on COOL mode, after a while, it will auto swing to its maximum angel for system protection. 3 minutes later, the horizontal air flow louver will resume to its original position.

Anti-ice function

- When PT=2℃, the compressor does not stop and indoor fan runs at high speed.
- When PT≤-1℃ for 1 minute, the compressor and outdoor fan stop and indoor fan runs at high speed.
- When PT≥8℃ for 5 minutes, anti-ice protection deactivates, both the compressor and the outdoor fan start operation.



CONTROL SPECIFICATION

HEAT MODE

- If the air conditioner is off and then turned on while set at COOL, HEAT or DRY mode, it will take approximately 3 minutes for the compressor to start.
- The ST at heat mode is adjustable within 16℃-31℃.
- When RT≥ST, the compressor stops; when RT<ST-1℃, the compressor starts.
- Once turning on the unit while set at heat mode, if all the conditions meet with the requirement of compressor operation, the four-way valve gets charged and 8 seconds later, the compressor and outdoor fan start running.

Strong-wing prevention :

- A.PT<27, the indoor fan stops running, the swing louver cannot be controlled by the remote controller.
  B.34>PT≥27, the indoor fan runs at low speed, the sweep louver erects.
  C.PT≥34, the indoor fan and the swing louver can be controlled normally.

Heat overload protection:

- For 7000BTU/h Model, when PT≥47℃, the outdoor fan stops; when PT≤42℃, the outdoor fan starts; when PT≥60℃, the compressor stops.
- For 9000BTU/h Model, when PT≥50℃, the outdoor fan stops; when PT≤47℃, the outdoor fan starts; when PT≥63℃, the compressor stops.
- For ≥9000BTU/h Model, when PT≥55℃, the outdoor fan stops; when Pt≤50℃, the outdoor fan starts; when PT≥63℃, the compressor stops.

Deice control:

- Conditions for activating deice:
  a. The working hours of compressor accumulates to be 40 minutes.
  b. When OT≤-4℃ for 1 minute.
- Conditions for terminating deice:
  a. When OT≥15℃ for 1 minute.
  b. Over 10 minutes of deicing operation.

Electric-heat control:

- Conditions for initiating electric-heat function:
  a. RT≤23℃; b. RT+3℃≤ST; c. The indoor fan runs;
  d. Turn on the electric-heat key; e. PT<50℃
- Conditions for terminating electric-heat function:
  a. PT≥50℃; b. RT≥26℃; c. The indoor fan stops running;
  d. Turn off the electric-heat key; e. Mode change.
- Conditions for terminating electric-heat function:
  a. PT≥50℃; b. RT≥26℃; c. The indoor fan stops running;
  d. Turn off the electric-heat key; e. Mode change.



CONTROL SPECIFICATION

DRY MODE

- In this mode, the air conditioner automatically sets the room temperature and this temperature is incontrollable by remote controller. The initial ST =RT-2℃.
- Control during dry mode:
  a. When RT<15℃, dry mode is not available; when RT≥15℃, the compressor intermittently runs under the influence of TS and RT.
  b. When RT≥23℃, if RT≥ST, the compressor runs intermittently as this:
  Run for 8 minutes ⟶ Stop for 3 minutes
  If RT<ST, the compressor runs intermittently as this:
  Stop for 4 minutes ⟶ Run for 1 minute
  c. When RT<23℃, if RT≥ST, the compressor runs intermittently as this:
  Run for 2 minutes ⟶ Stop for 3 minutes
  If RT<ST, the compressor runs intermittently as this:
  Stop for 4 minutes ⟶ Run for 1 minute
  d. In this mode, the indoor fan keeps running at low speed with the same pace as the compressor, and this speed can not be controlled by remote controller.

AUTO MODE

- In this mode, the air conditioner can automatically adjust the room temperature to decide the most suitable temperature. At the start of operation, the unit will automatically select the operation mode according to the room temperature. The following table shows the conditions which are set at start up.

Room Temperature (RT)	Cool only type		Heat pump type	
	Mode	Initial Setting Temperature	Mode	Initial Setting Temperature
RT≥26℃	Cool	24℃	Cool	24℃
26℃>RT≥25℃		RT-2		RT-2
25℃>RT≥23℃	Dry	RT-2	Dry	RT-2
RT<23℃		21℃	Heat	26℃

- Auto mode entering
  a. Once some operation mode is determined, it can not be changed even if the RT has altered.
  b. You can change the operation mode by remote controller.
- If restart within 2 hours, the unit will resume the same operation mode as before.
  If restart after 2 hours, the unit will select the operation mode according to the initial room temperature.
- At auto mode the ST can only be set + or - 2 ℃ of the RT.

CONTROL SPECIFICATION

FAN MODE

- Indoor fan runs at the set speed while compressor and outdoor fan are turned off.
- Indoor fan speed can be adjusted for low, medium and high.

SLEEP MODE

Sleep mode in cooling and drying running.

A. The indoor fan runs at low speed.

B. After one hour of operation the set temperature will increase by 1℃. One hour later, the set temperature will increase by 1℃ once more. The unit will then continue operating at 2℃ above the set temperature.

Sleep mode in heating running.

A. The indoor fan runs at low speed.

B. After one hour of operation the set temperature will decrease by 2℃. One hour later, the set temperature will decrease by 2℃ once more. The unit will then continue operating at 4℃ below the set temperature.

TO DISASSEMBLE MECHANICAL PARTS

Stop operation of the air conditioner and remove the power cord before repairing the unit.
The following pictures taking L1 series as an example are presented just for the purpose of illustration.

Indoor unit

No	Parts	Procedure	Remark
1	Front grille	1.Stop the air conditioner operation and block the main power. 2.Contract the second finger to the left ,and right handle and pull to open the inlet grille.	
		3.Draw away signal line.	
		4.Take the left and right filter out.	
		5. Loosen two fixing screw of front grille.	
		6.Put hands at the two ruts of the body, then pull the front panel out .	

TO DISASSEMBLE MECHANICAL PARTS

No	Parts	Procedure	Remark
2	Electrical parts	1.Loosen the earth screw in evaporator.	
		2.Loosen the stepping motor line, and pull softly the indoor pipe temperature sensor out from the pipe casing.	
		3.Push the hook outside to take the electrical box out easily.	
		4.Separate the electrical box from the indoor unit.	
3	Ass'y tray drain	1.Push the left and right hooks to make the ass'y pulled out.	

TO DISASSEMBLE MECHANICAL PARTS

No	Parts	Procedure	Remark
		2.Separete the ass'y tray drain from the body.	
4	Evaporator	1.Push the left hook and separate the left part out of evaporator.	
		2.Push the right hook and separate the right part out of evaporator.	
		3.Separate the evaporator from the indoor unit.	
5	Fan motor and cross fan	1.Separate the fan motor from the fan.	

Outdoor unit

No	Parts	Procedure	Remark
1	Cabinet	1.Turn off the unit and remove the power cable. 2.Remove the upper cabinet, the front cabinet and back cabinet.	
2	Fan motor & propeller fan	1.Remove the nut flange. (Turn to the right to remove as it a left turned screw) 2.separate the propeller fan from fan motor. 3.Loosen the fixed screw of fan motor,separate the fan motor from outdoor unit	
3	Ass'y control out	1.Loosen the fixing screw of the base-electrical control . 2.separate the connector. 3.Separate the ass' y control out from the outdoor unit.	  

Exploded Views and Parts List

Indoor unit

AUS-07C(H)53R010Lx AUS-09C(H)53R010Lx AUS-07C(H)53R150Lx
AUS-12C(H)53R130Lx AUS-12C(H)53R150Lx AUS-09C(H)53R150Lx



Exploded Views and Parts List

Indoor unit

AUS-07C(H)53R010Lx AUS-09C(H)53R010Lx AUS-07C(H)53R150Lx
AUS-12C(H)53R130Lx AUS-12C(H)53R150Lx AUS-09C(H)53R150Lx

No.	English Part Name	qty.	remark	No.	English Part Name	qty.	remark
1	air filter	2	left and right are sameness	26	Drain hose	1	
2	Front panel	1	L14、L15、L16 parted as upper panel and lower panel	27	Electrical control cover	1	
3	LED	1		28	Indoor display panel	1	L1、L17(display piece)，L15(transparency piece)，L15without
4	Electrical control box	1	L14(control box)，L15(display box)，L16 without，L17without	29	Decorate ring	1	L1、L3、L16、L18 without，L15(decorate tape)，L17(decorate board)
5	Enclosure	1					
6	Swing louver	1					
7	Water collecting tray	1					
8	Evaporator	1					
9	Indoor unit fan	1					
10	Oil bearing	1					
11	Rubber bear support	1					
12	Bottom enclosure	1					
13	Power supply cord clip	1					
14	Electrical control box	1					
15	Indoor unit terminal block	1					
16	Transformer	1					
17	Mounting plate	1					
18	Main control board	1					
19	Power supply cord	1					
20	Room temperature sensor	1					
21	Pipe temperature sensor	1					
22	Pipe fixing plate	1					
23	fan motor	1					
24	Electrical holder	1					
25	Stepping motor	1					

Outdoor unit AUS-07C53R010Lx AUS-09C53R010Lx



Outdoor unit AUS-07C53R010Lx AUS-09C53R010Lx

No.	English Part Name	Quantity	No.	English Part Name	Quantity
1	Air outlet grille	1			
2	Front panel	1			
3	Left handle	1			
4	Top cover	1			
5	Outdoor unit fan	1			
6	Outdoor fan motor	1			
7	Outdoor fan motor supporter	1			
8	Condenser	1			
9	Partition	1			
10	Electrical install board supporter	1			
11	Left back side plate	1			
12	Back cover	1			
13	right back side plate	1			
14	Electrical install board	1			
15	Capacitor fixing clip	1			
16	Outdoor unit terminal block	1			
17	power supply cord clip	1			
18	capacitor for Compressor	1			
19	Fan motor capacitor	1			
20	Capillary assembly	1			
21	High pressure valve	1			
22	Low pressure valve	1			
23	valve board	1			
24	Compressor screw	3			
25	Compressor	1			
26	Bottom board	1			
27	Right handle	1			

Outdoor unit AUS-07H53R010Lx AUS-09H53R010Lx



Outdoor unit AUS-07H53R010Lx AUS-09H53R010Lx

Number	Name	Quantity	Number	Name	Quantity
1	Air outlet grille	1	28	Right handle	1
2	Front panel	1	29	Outdoor pipe sensor	1
3	Left handle	1			
4	Top cover	1			
5	Outdoor unit fan	1			
6	Outdoor fan motor	1			
7	Outdoor fan motor supporter	1			
8	Condenser	1			
9	Partition	1			
10	Four way valve	1			
11	Electrical install board supporter	1			
12	Left back side plate	1			
13	Back cover	1			
14	Right back side plate	1			
15	Electrical install board	1			
16	Capacitor fixing clip	1			
17	Outdoor unit terminal block	1			
18	Power supply cord clip	1			
19	Capacitor for Compressor	1			
20	Fan motor capacitor	1			
21	Capillary assembly	1			
22	High pressure valve	1			
23	Low pressure valve	1			
24	Valve board	1			
25	Compressor screw	3			
26	Compressor	1			
27	Bottom board	1			

Outdoor unit AUS-12C53R150Lx AUS-07C53R150Lx AUS-09C53R150Lx



Outdoor unit AUS-12C53R150Lx AUS-07C53R150Lx AUS-09C53R150Lx

No	English Part Name	Quantity	No.	English Part Name	Quantity
1	Air outlet grille	1	26	Outdoor fan motor supporter	1
2	Front panel	1			
3	Outdoor unit fan	1			
4	Partition	1			
5	Valve board	1			
6	Compressor screw	3			
7	Power supply cord fixing	1			
8	Power supply cord clip	1			
9	Capacitor for compressor	1			
10	Electrical install board	1			
11	Right side board	1			
12	Top cover	1			
13	Fan motor capacitor	1			
14	Outdoor unit terminal block	1			
15	High pressure valve	1			
16	Capillary assembly	1			
17	Low pressure valve	1			
18	Compressor	1			
19	Bottom board	1			
20	Condenser	1			
21	Uphold board	1			
22	Capacitor fixing clip	1			
23	Fan motor (out door)	1			
24	Fan screw nut M8	3			
25	Right handle	1			

Outdoor unit AUS-12H53R150Lx AUS-07H53R150Lx AUS-09H53R150Lx



Outdoor unit AUS-12H53R150Lx AUS-07H53R150Lx AUS-09H53R150Lx

No.	English Part Name	Quantity	No.	English Part Name	Quantity
1	Air outlet grille	1	26	Right handle	1
2	Front panel	1	27	Outdoor fan motor supporter	1
3	Outdoor unit fan	1			
4	Partition	1			
5	Valve board	1			
6	Compressor screw	3			
7	Power supply cord fixs	1			
8	Power supply cord clip	1			
9	Capacitor for compressor	1			
10	Electrical install board	1			
11	Right side board	1			
12	Top cover	1			
13	fan motor capacitor	1			
14	Outdoor unit terminal block	1			
15	High pressure valve	1			
16	Capillary assembly	1			
17	Low pressure valve	1			
18	Four way valve	1			
19	Compressor	1			
20	Bottom board	1			
21	Condenser	1			
22	Uphold board	1			
23	Capacitor fixing clip	1			
24	Fan screw nut M6	1			
25	Fan screw nut M8	3			

Outdoor unit AUS-12C53R130Lx



Outdoor unit AUS-12C53R130Lx

No.	English Part Name	Quantity	No.	English Part Name	Quantity
1	Air outlet grille	1			
2	Front panel	1			
3	Outdoor unit fan	1			
4	Outdoor fan motor	1			
5	Outdoor fan motor supporter	1			
6	Left handle	1			
7	Left back side board	1			
8	Condenser	1			
9	Back cover	1			
10	Fixed board	1			
11	Top cover	1			
12	Fan motor capacitor	1			
13	Capacitor for Compressor	1			
14	Electrical install board	1			
15	Capacitor fixing clip	1			
16	Outdoor unit terminal block	1			
17	Power supply cord clip	1			
18	Right handle	1			
19	Right back side board	1			
20	Capillary assembly	1			
21	High pressure valve	1			
22	Low pressure valve	1			
23	Valve board	1			
24	Compressor	1			
25	Bottom board	1			
26	Partition	1			

Outdoor unit AUS-12H53R130Lx



Outdoor unit AUS-12H53R130Lx

No.	English Part Name	Quantity	No.	English Part Name	Quantity
1	Air outlet grille	1			
2	Left handle	1			
3	Front panel	1			
4	Outdoor unit fan	1			
5	Partition	1			
6	Top cover	1			
7	Left back side plate	1			
8	Condenser	1			
9	Right back side plate	1			
10	Right handle	1			
11	Fan motor capacitor	1			
12	Capacitor for Compressor	1			
13	Electrical install board	1			
14	Outdoor unit terminal block	1			
15	Power supply cord clip	1			
16	Outdoor fan motor supporter	1			
17	Outdoor fan motor	1			
18	Four way valve	1			
19	Capillary assembly	1			
20	High pressure valve	1			
21	Valve board	1			
22	Low pressure valve	1			
23	Compressor	1			
24	Back board	1			

Wiring Diagrams

Indoor unit

AUS-07C53R010Lx AUS-09C53R010Lx AUS-07C53R150Lx
AUS-12C53R130Lx AUS-12C53R150Lx AUS-09C53R150Lx



Outdoor unit

AUS-07C53R010Lx AUS-09C53R010Lx AUS-07C53R150Lx
AUS-12C53R130Lx AUS-12C53R150Lx AUS-09C53R150Lx



Indoor unit AUS-07H53R010Lx AUS-12H53R130Lx AUS-09H53R010Lx



Outdoor unit AUS-07H53R010Lx AUS-12H53R130Lx AUS-09H53R010Lx



Indoor unit AUS-12H53R150Lx AUS-07H53R150Lx AUS-09H53R150Lx



Outdoor unit AUS-12H53R150Lx AUS-07H53R150Lx AUS-09H53R150Lx